airwrap i.d.

Dyson Airwrap i.d logo

User manual




In the box
Getting started
Connecting to the MyDyson™ app
Using your attachments
Pre-styling
Curling

Shaping
Volumizing
Smoothing
Diffusing
Stretching
Regular filter maintenance



In the box



A cylindrical tool that fits on to the filter at bottom of the Dyson Airwrap multi-styler for cleaning.



Filter cleaning brush

You can buy additional attachments at www.dyson.com.sg/products/hair-care/hair-stylers/airwrap-id/accessories



dryer main body

30mm Airwrap™ barrel



40mm Airwrap™ barrel



20mm Airwrap™ barrel



30mm Airwrap™ Iong barrel



40mm Airwrap™ long barrel



Conical Airwrap™ barrel



Soft smoothing brush



Firm smoothing brush



Small soft smoothing brush



Small firm smoothing brush



Small round volumizing brush



Round volumizing brush



Large volumizing round brush



Dryer+ Flyaway smoother



Fast dryer




Blade concentrator



Diffuser

Getting started



Unlock i.d. curl[™] personalized curling sequence by connecting to the MyDyson[™] app

Download on the App Store. Get it on Google Play.

Step '

Download the MyDyson™ app and create your account. If you already have an account, log in.

Step 2

Power on your Dyson Airwrap i.d.™ multi-styler and dryer and add machine to the app.
Bluetooth* wireless technology must be enabled on your mobile device.

Step 3

Follow the steps to pair your Airwrap i.d.™. Airflow will be active during this time.

Step 4

Once paired, power off your Airwrap i.d.™. Continue set-up in the app to enable features such as the i.d. curl™ personalized curling sequence.

MyDyson™ app connectivity

App functionality may vary per market. Requires internet connection. Operating system and mobile device requirements for the MyDyson™ app can be found on the App Store or Google Play.

Apple, the Apple logo and Siri are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of the Apple Inc., registered in the U.S. and other countries. Google Play, the Google Play logo, Google Assistant are trademarks of Google Inc.

Logos of MyDyson app, App store and Google Play.












Using your attachments

Connecting the attachment

Turn attachment into the main body until it fits securely.

Changing attachments

To change attachment, pull down on the switch to release.



Cool touch tip


During use, the Dyson Airwrap™ barrels, round brushes and Dryer+Flyaway smoother will get hot. To change to another attachment, hold the tip.

Hold onto the rotating cool tip at the top end of the attachment, pull down on the release switch and lift the attachment away.

Take care when handling hot attachments

Hold the attachment only in the area indicated. Some attachments may need occasional cleaning.

For more information, go to www.dyson.com/hair-care/accessories



Pre-styling

For straight and wavy hair, use a dryer attachment – Fast dryer or Dryer+Flyaway smoother.

The Dryer+Flyaway smoother has two modes (i) drying and (ii) smoothing. Use the cool tip to switch between the modes.

Hair should look dry but feel cold to the touch before curling with barrels.

For curly and coily hair, use the Firm smoothing brush. Brush hair downwards in small sections, starting from the ends and working towards the roots, until slightly damp to touch.



A person holding the device with the Coanda smoothing dryer attachment above their head, with airflow blowing their long, straight hair.

A person moving the device with the Coanda smoothing dryer attachment down their hair to hide flyaways.



Curling

Using i.d. curl[™] sequence

The Dyson Airwrap i.d.™ multi-styler and dryer remembers your personalized i.d. curl™ sequence. This tailors wrapping and styling times to your personal hair profile, using the MyDyson™ app.

Slide up and release the power switch to activate i.d. curl™ sequence, following initial app set-up.

Barrels Step 1


Take a section of hair and bring barrel towards tips. Hair will start to wrap around barrel.

Step 2Move styler towards head, no need to twist. Your personalized i.d. curl™ sequence will run.

Step 3 Cold shot will automatically activate to set the curl. Airflow will automatically reduce when sequence is complete.

Move device downwards to release.

To change curl direction, rotate the barrel's cool tip.



Shaping

Smoothing brushes

Use Smoothing brush to brush from root to tip.

Tip:

For volume, face bristles outwards. Turn brush inwards at the ends to create shape. A person using the Smoothing brush attachment with bristles facing inwards and running along the length of roughdried hair.

In g brush acing mbing hair As the set the hair chment is ds to help

The Smoothing brush with bristles facing outwards combing hair near the tips. As the brush reaches the hair tips, the attachment is turned inwards to help create shape.

Volumizing

Round volumizing brush


The Round volumizing brush has long fine bristles to direct air into the hair whilst giving body, creating tension to shape the hair as it dries.



Tip
Lift sections upwards as you dry to add volume.
Wrap hair around and under the brush to shape the ends



The Round volumizing brush with a length of hair over the top of it and to an angle as it brushes from root to tip.



The Round volumizing brush showing the hair curled around shaping the ends.

Smoothing

Dryer+Flyaway smoother Rotate cool tip to select Smoothing mode. Press against hair to switch airflow direction. On the side of the Dryer+Flyaway smoother, twist the rotating cool tip to select Smoothing mode. Run the attachment downwards to the hair tips.





Use on dry hair to hide flyaways.
Position against hair until it attracts then slowly run down to tips.

For use on dry and straight hair.

How to use the contact bar

Position contact bar against the head until you hear a click and hair attracts. Run from root to tip to hide flyaways.

A person using the Dryer and Flyaway smoother on dry, straight hair, moving the attachment along roots to tips of hair.

Regular filter maintenance

Filter cleaning is overdue when the white LED starts flashing.

Ensure that you unplug your appliance from the mains electricity supply and allow to cool down before cleaning your filter.

The Dyson Airwrap i.d. $^{\text{\tiny{IM}}}$ multi-styler and dryer has highly tuned technology to give outstanding performance.

This technology needs to be kept free from dust and hair product residue. Maintenance is required to maintain performance.



Filter mesh



Filter cleaning brush



Filter cage

Step 1

Slide the filter cleaning brush over the cable and onto the filter cage.

Using a rotating action, clean the filter cage thoroughly.

Remove the filter cleaning brush.

Slide the filter brush onto the filter cage and rotate from side to side and upwards and downwards to clean the filter cage.



Step 2

Hold the handle of your appliance and pull the filter cage downwards, onto the cable.

Gently pull open the filter cage and slide it off the cable.



Gently pull the filter cage downwards towards the cable.
Open the filter cage and remove.

Wash the filter cage under the tap.

Step 3 Wash the filter case under

Wash the filter cage under a warm, running tap.


Step 4

Shake the filter cage to remove the majority of the excess water, then leave to dry naturally.

Step 5

Using a rotating and up and down action, clean the filter mesh with the filter cleaning brush until all the debris has been removed.

Do not use water or chemicals to clean the filter mesh.



Slide the filter cage towards the handle and twist until it snaps into place.





Rotate the filter brush from side to side and upwards and downwards around filter mesh to clean.



Slide the filter brush towards the filter.



Gently open the filter cage and slide the cage towards the handle, twist until it snaps into place.